


W 125 FL


Flueless Singlepoint Water Heater
with Atmosphere - Sensing Device

GC NUMBER
52-311-022

USER INSTRUCTIONS & CUSTOMER CARE GUIDE



EXCELLENCE COMES AS STANDARD



Thank you for purchasing a Worcester W125 gas-fired water heater.

The Worcester W125 appliances are made by Bosch Thermotechnic and the strictest quality control standards are demanded throughout every stage of production.

Indeed, Worcester Heat Systems have led the field in innovative appliance design and performance for more than 30 years.

The result is that your new Worcester W125 appliance offers you the very best of everything - quality, efficiency, economical running costs, proven reliability and value for money.



What's more, you also have the assurance of our no-nonsense 1 year parts and labour guarantee.

And it's backed up by Worcester Care Call - a complete maintenance scheme to keep your water heater operating at peak condition and efficiency.

No wonder that more and more people are agreeing that when it is gas, it has to be Worcester.

CONTENTS

	Page No.
Operating Instructions	3-9
Fault and Breakdowns	10
Maintenance and Extended Warranty Information	11-13
Guarantee Details	16



GENERAL INFORMATION

GAS SAFETY (INSTALLATION AND USE) REGULATIONS 1998

It is the law that all gas appliances must be installed by a competent person in accordance with the above regulations. Failure to correctly install appliances correctly could lead to prosecution. It is in your interest and that of safety to ensure compliance with the law. The manufacturers notes must not be taken, in any way, as over-riding statutory obligations.

IMPORTANT: To get the best from your Worcester W125 please read these instructions carefully.

NOTE: In the event of a fault the appliance should not be used until the fault has been corrected by a competent person.

GENERAL DESCRIPTION

The W125 is a flueless gas fired singlepoint water heater.

The appliance does not require a flue. It is essential that the correct installation requirements are satisfied. This appliance is intended for intermittent use only and should not be in use for more than 5 minutes in any one draw-off, must not be positioned in or adjacent to a bedroom or any room containing a bath or shower.

It is the law that all gas appliances are installed by a Corgi registered installer.

Failure to correctly install appliances can lead to prosecution.


Technical Data


Appliance Type	W125	
	Nat. gas	L.P.G.
Rated Input (Qn)	10.4 kW	10.4 kW
Maximum Rated Output (Pn)	8.7 kW	8.7 kW
Minimum Rated Output (Pmin)	4.4 kW	4.4 kW
Gas Rate (maximum)	1.1 m ³ /h	0.8 kg/h

Performance


Temperature control turned fully anti-clockwise
5 litres/minute at 25°C temperature rise

Temperature control turned fully clockwise
2.5 litres/minute at 55°C temperature rise





GENERAL NOTES



CLEARANCES

Your installer will have provided adequate space around the appliance for safety and servicing. Do not restrict this space by the addition of cupboards, shelves etc. close to the appliance.

Minimum clearances in millimetres.

Above	300 mm
In front	600 mm
Below	150 mm
Right hand side	10 mm
Left hand side	10 mm

SHOWERS, BIDETS, TAPS AND MIXING VALVES

The W 125 heater must not be connected to a bath or hot water draw-off located in different rooms to where the heater is installed. The W 125 water heater is designed for installation over the sink to deliver hot water either through a swivel spout or to a hot water tap at the sink or basin.

HOT AND COLD FLOW

If the flow of water demanded from both hot and cold service outlets is dependent upon mains supply, it may not be possible in some installations to operate all outlets simultaneously.

WATER MAINS FAILURE

It is important to note that in the event of a mains water supply failure, no tap water will be available until the mains supply is restored.

USE IN HARD WATER AREAS

Normally there is no need for scale protection. However, in areas of exceptionally hard water supply it is recommended that an In-Line scale inhibitor be fitted.

Installation should be strictly in accordance with the requirements of the local Water Company. An isolating valve to facilitate servicing should be incorporated.

The water hardness may be determined using the standard test paper or by reference to the local Water Company.

Further information may be obtained from Worcester Heat Systems Technical Helpline.

FROST PRECAUTIONS

If the appliance is not to be used for a long period of time and there is a likelihood of freezing, then the appliance should be drained. The Worcester Heat Systems Technical Helpline will advise you on suitable frost precautions.

SERVICE

Annual servicing is important in order to ensure continuing high efficiency and long life for your appliance. In the event of any difficulty in making suitable servicing arrangements, Worcester Heat Systems Limited or other competent persons will discuss regular servicing arrangements and offer a comprehensive maintenance contract.

WARNING

If a gas leak exists, or is suspected, turn off the gas supply to the appliance at the service cock and consult your local service engineer.

Do not touch any electrical switches to turn them either on or off. Open all windows and doors. Do not smoke. Extinguish all naked lights.

CLEANING

Do not use abrasive cleaners on the outer casing. Use a damp cloth and a little detergent.


SAFETY FEATURES

Your Worcester W 125 is fitted with an atmosphere-Sensing Device which must not be altered in any way.


1.) If the air in the room in which the heater is situated becomes depleted of oxygen the pilot will be extinguished automatically.

2.) If the flue outlet is obscured or the heat exchanger becomes blocked again the pilot will be extinguished automatically.

Note: If the pilot is extinguished during use, the room should be ventilated before attempting to re-light.



OPERATION OF CONTROLS



Operation


Starting up (see fig. 2)

Move the gas control slide to the ignition position. Observe the pilot burner. Press in the central button of the control slider and hold depressed while pushing the Piezo igniter button two or three times. The pilot should light. Wait approximately twenty seconds and then release the centre button of the control slider.

The pilot should remain alight. If the pilot does not light, repeat the operation until a flame is established.

Note: On initial light up, or after any prolonged shut down, the pilot may take several attempts to establish due to the presence of air in the gas supply system.

Gas control slide - ignition position




Gas control slide - output control (see fig. 3)

After successful ignition move the slide control to the right positioning it according to your output requirement. The further to the right you position the slide control the higher the output, and consequently the higher the consumption of gas.


Maximum output is obtained when the slide control is to the far right.

In order to optimize energy consumption, adjust slide control position to supply the minimum output required.



Temperature Control (see fig. 4)

The temperature Control Knob should be turned anti-clockwise to obtain a higher flow rate of water at a lower temperature rise, or turned clockwise to obtain a higher temperature rise at a lower flow rate.




Shut Down (see fig. 5)

When there is no demand for hot water over a long period, the pilot can be extinguished by moving the slide control fully to the left.

When hot water is required again, the pilot must be re-established.

If, during prolonged inactive periods, there is any risk of freezing, the heater should be drained by firstly isolating the appliance from the incoming cold water supply (close the water cock). Then open the taps and drain down.



Servicing

To ensure continued efficient operation of the appliance it is recommended that it is checked and serviced as necessary at regular intervals.

The frequency of servicing will depend upon the particular installation conditions and usage but in general once a year should be adequate.

It is the law that any service work be carried out by a competent person such as British Gas or other Corgi registered personnel.

The casing should be wiped clean using a damp cloth

Do not use abrasive or corrosive cleaners

Fig. 6 - Controls






Fig. 6

- | | |
|----------------------|-----------------------------------|
| 1 Observation window | 6 Hot water tap |
| 2 Pilot flame | 7 Water flow selector |
| 3 Piezo igniter | 8 Cold water tap |
| 4 Gas control slide | 9 Cold water inlet isolating cock |
| 5 Screw | 10 Gas isolating cock |



APPLIANCE FAILS TO OPERATE



More than 30% of all calls made to Worcester Heat Systems to report appliance faults or breakdowns prove to be false alarms, as there is often a simple explanation for the apparent malfunction.

So, to help you save time and money - not to mention frustration and inconvenience - please refer to the General Information, Notes and Lighting Instructions ensuring all controls are set correctly.

If, after following the instructions the appliance still fails to operate correctly call the Worcester Heat Systems Service Centre.

Arrangements will be made for an engineer to call as soon as possible.

CALL-OUT CHARGES

All of our field service engineers are factory trained.


If you request a visit from an engineer and your appliance has been installed within the last 12 months, no charge will be made for parts and/or labour, providing:

- The appliance was commissioned correctly on installation.
- An appliance fault is found and the appliance has been installed within the past 12 months.


A call-out charge will be made where:

- The appliance has been installed for over 12 months, or
- Our Field Service Engineer finds no fault with the appliance (see note), or
- The cause of breakdown is with other parts of your plumbing/heating system, or with equipment not supplied by Worcester.

NOTE: Invoices for attendance and/or repair work carried out on your appliance by any third party will not be accepted.



MAINTAINING YOUR APPLIANCE




Your new Worcester gas-fired appliance represents a long-term investment in a reliable, high quality product.


In order to realise its maximum working life, and to ensure it continues to operate at peak efficiency and performance, it is essential that your boiler receives regular, competent servicing and annual maintenance checks beyond the initial 12 month guarantee period.

Regular service contracts can be arranged with your installer - however if you have difficulty making a satisfactory arrangement simply contact Worcester Heat Systems on 0345 256206 for help.

If you would like to know more about Worcester's extended warranty options please tick the appropriate box on your registration card.



SERVICE CENTRES



Region	Telephone	Fax	Opening Hours (Mon to Fri)	Sat
Scotland	0345 256206	(01506) 441687	8.00 am to	9.00 am to
The rest	0345 256206	(01905) 757536	6.00 pm	1.00 pm


We have Service Centres situated throughout the country.

If you have a service request simply call our local rate number above and your request will be routed to your Regional Service Centre.


NOTE:

Should you have a service request outside normal office hours, please leave a recorded message giving as much information as possible to assist the administrator to deal with your request.

If the visit of an engineer is necessary your administrator will confirm any arrangement made.




YOUR WORCESTER W125 GUARANTEE




This appliance is guaranteed against faulty materials or workmanship for a period of twelve calendar months from the date of installation subject to the following conditions and exceptions.

1. That during the currency of this guarantee any components of the unit which are proved to be faulty or defective in manufacture will be exchanged or repaired free of material charges and free of labour charges by Worcester Heat Systems Limited.
2. That the householder may be asked to prove the date of installation, that the appliance was correctly commissioned and, where appropriate, the first 12 month service has been carried out to the satisfaction of Worcester Heat Systems Limited when requested.
3. That any product or part thereof returned for servicing under the guarantee must be accompanied by a claim stating the Model, Serial Number, Date of Installation.
4. That Worcester Heat Systems Limited will not accept responsibility for damage caused by faulty installation, neglect, misuse or accidental damage, the non-observance of the instructions contained in the installation and Operating Instructions Leaflets.
5. That the appliance has been used only for normal domestic purposes for which it was designed.
6. That this guarantee applies only to equipment purchased and used in mainland Great Britain.

This guarantee is given in addition to all your normal statutory rights.



GUARANTEE REGISTRATION



You should complete and return the postpaid Guarantee Registration Card within 14 days of purchase.

The card will register you as the owner of your new Worcester appliance and, while this will not affect your statutory rights in any way, it will assist us to maintain an effective and efficient customer service by establishing a reference and permanent record for your boiler.

IMPORTANT: SERIAL NUMBER. Copy the number off the Guarantee Card.

FOR YOUR OWN RECORD

MODEL

SERIAL NUMBER

(See identity label inside appliance casing)

TYPE/SIZE

DATE OF INSTALLATION



EXCELLENCE COMES AS STANDARD

Worcester Heat Systems Limited, Cotswold Way, Warndon, Worcester WR4 9SW.
Telephone: (01905) 754624. Fax: (01905) 754619 Technical Helpline (0990) 266241

6 720 606 019 (01.09) AL