# STRAY LIGHT KIT (5140003)

# Why do I need this kit?

The light baffle fitted to your heater may have been incorrectly set or moved in transit. This can result in an unwanted band of orange light appearing in front of the heater.

# What is in the kit?

Along with this guide you should have received a length of rubber 'U' section.

# Do I need any tools?

No, the rubber 'U' section simply pushes into place.

# How do I fit the 'U' section?

**Ensure that the heater is 'OFF' and completely cool before continuing.** Firstly you need to identify the light baffle. This is the black, rectangular metal bracket that is above the effects screen. Please see figure 1.



Effects screen

Fig. 1

Using a suitable pair of scissors, cut a length of rubber 'U' section to the width of the light baffle. Place the 'U' section over the whole length of the light baffle. Please see figure 2.



Fig. 2

With the 'U' section in place the light baffle should appear as in figure 3. If a small amount of stray light remains the rubber 'U' section can be raised slightly along its length.

