



WORCESTER

Bosch Group

INSTALLATION INSTRUCTIONS FOR THE OPTIONAL FILLING KIT

WORCESTER 24CDi, 28CDi, 26CDi XTRA, 35CDi and BOSCH RX2

1. Install the appliance manifold in the desired position and connect all pipework. (See installation instructions packed with the appliance)
2. Secure the filling device as shown in the diagram below using the retainers and M6 hexagonal headed screws supplied in the kit, ensuring that the manifold "O" rings are fitted correctly, clean and lubricated.
3. Ensure that all isolating valves on the manifold are closed and then open the valve on the flow connection only.
4. Open the valve on the cold water inlet and fill the system until the desired pressure is reached. (N.B.: A 3 bar maximum pressure relief valve is fitted to the filling device).
5. Close the cold water valve when the system is full and, after ensuring that all other valves are closed, remove the filling device.

The system may now be left full or drained as required.