

Publication No. ZZ724/2
January 2006

CL3 TIME CONTROL

**User's Operating
Instructions**



**Johnson
& Starley**

CL3 Time Control


Use tappets to choose programme times - notes below explain how.

These hands show time of day

OFF position of switch keeps clock running, but heater will not operate.

With switch OFF heater will operate normally.

OFF position of switch keeps clock running, but heater will not operate.



Clock dial turns clockwise. DO NOT TURN ANTICLOCKWISE

Black pointer shows time on clock. 12 noon would show 12 in line with pointer.

Slide switch to LEFT to use programme times. Slide switch to RIGHT for continuous heater operation.

With switch ON cool air will circulate continuously.

Slide switch to LEFT to use programme times. Slide switch to RIGHT for continuous heater operation.

NOTE: The clock dial may differ from your old clock, but the method of setting is the same.

To set the time of day, grip the perimeter of the dial and turn the dial **CLOCKWISE** - **DO NOT** attempt to turn it anticlockwise.

The shortest time period that can be set is 15 minutes (this being a single tappet). The ON times are set by pushing the tappets IN towards the centre of the dial, the OFF times by pulling the tappets OUT.

To set ON and OFF periods for TIMED operation:-

EXAMPLE:-

The ON times wanted are 07.30 to 09.00 in the morning and 16.30 (4.30) and 23.15 (11.15) in the evening.

- i) PUSH IN all tappets between 07.30 and 09.00 and all tappets between 16.30 and 23.15 (OFF periods are represented by those tappets remaining OUT).
- ii) Set the correct time of day by turning the dial CLOCKWISE until the actual time lines up with the pointer.
- iii) Set the switch to TIMED.
- iv) Set the thermista-stat/room thermostat to the desired setting; the heater will now operate during the times required.

Other operating conditions:-

- i) The heater(s) can be made to operate outside of the time control settings during any day (at weekends for example) by setting the appropriate switch to ON ALL TIME - the room and/or water temperatures will now be controlled automatically.
- ii) To return to the usual ON and OFF times, or overnight, or during the weekends, set the switch to TIMED.
- iii) If heating is NOT wanted, set the switch to the central OFF position.



Rhosili Road, Brackmills,
Northampton NN4 7LZ
Tel: 01604 762881
Fax 01604 767408
www.johnsonandstarley.co.uk