## MODELS 622, 622L & BR622 **INSTALLERS NOTES for "ELEGANT" VERSIONS**

Appliances under the brand name "Elegant" are supplied in a single pack with the fire front fitted to the burner & convection box unit.

The design of this front is similar to the "Visage" version described in the installer's and owner's guides. Please observe the following procedures instead of those given in the relevant sections of the installer's guide: -

"Elegant" front surround dimensions are the same as those shown for the "Visage". Figure 5;

3.1 **Check ignition spark**; Fit the battery as described in the installer's guide. Instead of rotating the control pivot bracket, slide the control button down far as it will go (see figure "A"). This should close the ignition circuit. Follow the checks as described in the installer's guide.

6.

6.0.1

6.0.2

instructions.

front instructions.

Short list of spares

Fig."A" Control ignition **Prepare appliance for installation;** The front unit must be removed as follows before detaching the burner unit: -Disconnect the control linking bar from the control pivot bracket by removing the knurled screw (see figure "B"). Remove the two screws securing the bottom of the front surround to the sides of the convection box. Make sure that the control linking bar has been detached. Carefully lift the front surround upwards to clear the upper retaining brackets on the convection box (see figure "C"). Pull the surround clear. Slide the control button upwards as far as it will go to prevent the bottom linkage bar from Fig. "B" Control bar & pivot bracket connection protruding below the surround and possibly being damaged. Place carefully aside. Then continue as described in the installer's guide from section 6.1 onwards. Where there are references to specific fronts in the installers guide, follow the "Visage" front **Servicing & Parts Replacement** Where there are references to specific fronts in the installers guide, follow the "Visage" The back wall (Key N in installer's guide) for "Elegant" versions is spare part no. 568229. Fig. "C" Front surround removal