

B A X I F I R E S D I V I S I O N

SERENITY FASCIA TRIM ADDENDUM

This guide is for use with the **Model 754** fitted with the ‘Serenity’ fascia. It must be read in conjunction with the installer and owner guide supplied with the gas fire.

As part of our policy of constant development and improvement the ‘Serenity’ fascia has been modified. The fascia trims are now permanently secured to the fascia and not held in place using magnetic tape as stated in the installer guide. The following changes to the installer guide are applicable:

Section 13.4 Fitting the Landscape and Serenity fascias.

Point 3. This can be ignored. There is no need to remove the fascia trims.

Point 7. Ignore that it says to refit the trims.

Section 16.1 To remove the fascia.

Landscape and Serenity models

Point 2. The following text contained in this section can be ignored:

Important: The Serenity fascia has six fascia trims that are held in place with magnetic tape. Before removing the Serenity fascia it is advisable to remove the side trims from the fascia. This will avoid the trims slipping and causing injury or damage. To remove them, hold firmly and pull gently clear. Place the trims away from the work area in a safe place.

B A X I F I R E S D I V I S I O N

SERENITY FASCIA TRIM ADDENDUM

This guide is for use with the **Model 754** fitted with the ‘Serenity’ fascia. It must be read in conjunction with the installer and owner guide supplied with the gas fire.

As part of our policy of constant development and improvement the ‘Serenity’ fascia has been modified. The fascia trims are now permanently secured to the fascia and not held in place using magnetic tape as stated in the installer guide. The following changes to the installer guide are applicable:

Section 13.4 Fitting the Landscape and Serenity fascias.

Point 3. This can be ignored. There is no need to remove the fascia trims.

Point 7. Ignore that it says to refit the trims.

Section 16.1 To remove the fascia.

Landscape and Serenity models

Point 2. The following text contained in this section can be ignored:

Important: The Serenity fascia has six fascia trims that are held in place with magnetic tape. Before removing the Serenity fascia it is advisable to remove the side trims from the fascia. This will avoid the trims slipping and causing injury or damage. To remove them, hold firmly and pull gently clear. Place the trims away from the work area in a safe place.