



GREENSTAR CAMRAY 12/18 OIL



Spare parts list




6720900607.AA

Cabinet Assembly Drawing
D

Camray 12/18

1

Spare parts list




672090060AD












Primary HT Exchanger Assembly
D

Camray 12/18


2

Spare parts list



- 33 
- 31 
- 30 
- 29 
- 28 
- 27 
- 26 
- 25 
- 24 
- 23 
- 22 

Spare parts list




6720900625.AA

Hydraulic Assembly
D

Camray 12/18

4

Spare parts list




672090061AC

Manifold Assembly
D

Camray 12/18

6

Spare parts list



6720900610.AA

Secondary HT Exchanger Assembly
D

Camray 12/18

8

**ADDITIONAL SPARE PARTS
FOR APPLIANCE
NOT DRAWN**

9099

6720900999.AA

Additional Spare Part
D

Camray 12/18

9

List of translations

Pos			
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
2			
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
Pos			
3			

List of translations

1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
4				
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
Pos				
21				
22				

