



BRAZILIA DISABILITY KNOB GUIDE

This disability knob is for Comfortstat models only.

Contents.

Description	Spares Number	Qty.	Picture (Not to scale)
Disability knob	5133806	1	
Hexagonal key		1	

Fitting the disability knob.

1. Ensure that the heater control is in the 'OFF' position.
2. The disability knob has been designed to fit over the existing control knob so there is no need to remove the existing control knob. Locate the disability control knob over the existing control knob as in figure 1.
3. There is a small grub screw in the side of the disability control knob. Using the hexagonal key supplied, tighten the grub screw until it is just tight. Do not over tighten the grub screw as this may cause damage.

© Baxi Heating U.K. Limited 2008.






Figure 1. Fitting the disability knob

BRAZILIA DISABILITY KNOB GUIDE

This disability knob is for Comfortstat models only.

Contents.

Description	Spares Number	Qty.	Picture (Not to scale)
Disability knob	5133806	1	
Hexagonal key		1	

Fitting the disability knob.

1. Ensure that the heater control is in the 'OFF' position.
2. The disability knob has been designed to fit over the existing control knob so there is no need to remove the existing control knob. Locate the disability control knob over the existing control knob as in figure 1.
3. There is a small grub screw in the side of the disability control knob. Using the hexagonal key supplied, tighten the grub screw until it is just tight. Do not over tighten the grub screw as this may cause damage.

© Baxi Heating U.K. Limited 2008.




Figure 1. Fitting the disability knob