BAXI FIRES DIVISION

'COAST' FASCIA ADDENDUM

This addendum is for the Model 827 Electric Heater. The 'Coast' fascia has been added to the product range. Please read this addendum in conjunction with the installer and owner guide supplied with the heater.

Page 4 - The following additional line of text must be added to the safety section.

Important safety instructions.

• The lifting weights of the heater parts are listed below: -

Heater	Heat engine (kg)	Complete Fascia (kg)	Spacer (kg)
Coast	6.8	5.1	2.3

Page 8 - The Heading at the top of the page now reads as below.

Adage and Fusion heaters plus Anthem, <u>Coast.</u> Minima and Style heaters supplied with a one piece fascia.

Page 15 - The section in the middle of the page now reads as below.

Fitting the one piece Anthem, <u>Coast</u>, Minima and Style fascia.

1. Removing the fascia may have moved the magnets used to fix the fascia to the heater. The magnets should be located as in figure 13.

2. Locate the fascia onto the heater. Ensure that the sides of the fascia sit on the floor / hearth.

Style model.

The rear of the firefront has two brackets that locate into slotted brackets on the heater.

Minima model.

The rear of the firefront has two slotted brackets that locate into slotted


brackets on the heater.

Anthem model.

Place the firefront in a central position against the fascia. **Coast** model.

- The heater is supplied with two firefront hanging brackets. Locate these at the side of the heater as in figure 18b. Secure using four screws supplied.
- The rear of the firefront has location arms that fit on to the heater brackets. Locate the firefront onto these brackets.

3. Place the loose pebbles / coals on top of the fuel support. It is not necessary to use all the pebbles / coals supplied.



BAXI • VALOR • WONDERFIRE

© Baxi Heating U.K. Limited 2005.