

LPG (PROPANE) CONVERSION INSTRUCTIONS

LPG Conversion Kit Number 0595209

Kit Consists of: -

| DESCRIPTION | SPARES NO. | QTY. | REFERENCE |
|-------------------------------------|-------------------|-------------|----------------------|
| ODS Unit | 0544929 | 1 OFF | OP "LPG9222" |
| Injector | 3003097 | 1 OFF | Bray Cat. No. 18/140 |
| LPG Conversion overlay (data) label | 3003099 | 1 OFF | |

NOTE – ALWAYS TURN OFF THE GAS SUPPLY BEFORE COMMENCING ANY SERVICING (THE INLET ELBOW FOR THIS APPLIANCE INCORPORATES AN ISOLATING VALVE)

1/ Replace NG ODS with LPG variant.

For instructions, please refer to relevant installation manual.

2/ Replace NG injector with LPG variant.

For instructions, please refer to relevant installation manual.

3/ Remove or slide the aeration collar up the mixer tube and away from the aeration slot so that the slot is fully open and clear of the collar.

4/ Peel off backing on LPG conversion data label and position onto the data plate thus covering the superceded NG data.

5/ Ensure gas soundness, sealing, spillage test and performance are satisfactory in accordance with current regulations.