


# SET Wallplate for the SET2E, SET3E and SET3M



## SET2E

*Link 1-5 at time of installation*

⏚	N	L	1	2	3	4	5	6
Mains Supply (via 3 amp fuse)			Water			Heating		
			ON	COM	OFF	ON	COM	OFF

## SET3E & SET3M

⏚	N	L	1	2	3	4	5	6
Mains Supply (via 3 amp fuse)			Water			Heating		
			ON	COM	OFF	ON	COM	OFF

## SET2E, SET3E and SET3M

NOTES:

FOR SET2E LINK  
TERMINALS 1 & 5

FP975 ON A SET  
WALLPLATE

