


Item Number	Part Number	Title
1	F820324	FASCIA ASSEMBLY - PIANO
2	F930160	HEATER & ELEMENT FER GAS - 54118
3	F930124	SWITCH - II - RED - EL006044/5
4	F930123	SWITCH - I - RED - EL006044/0
5	F930122	SWITCH - FAN - EL006250/0
6	F930121	SWITCH - ON / OFF - EL006036/0
7	F930060	BULB - RED - 60w
8	F780104	PEBBLE - KAVACHI - 14
9	F711351	SPINNER DOME - WHITE
10	F550306	KAVACHI FABRICATION
11	F820293	FASCIA ASSY - KAVACHI



**SPARE PARTS
PIANO & KAVACHI ELECTRIC FIRE**