

AERATION ADDENDUM

This addendum is for the following natural gas models: 939, 940 & 951. It must be read in conjunction with the installer and owner guide supplied with the fire.

Why?

Depending on the type of fuel effect used with the fire, the aeration setting on the burner may have changed from that specified in the installer guide.

What to do?

Ignore any reference to checking the aeration setting of the burner and the aeration setting illustration at the start of the 'Servicing and Parts Replacement' section. The aeration setting is factory set and will not require adjustment.

© Baxi Heating U.K. Limited 2009.

5135413/01



AERATION ADDENDUM

This addendum is for the following natural gas models: 939, 940 & 951. It must be read in conjunction with the installer and owner guide supplied with the fire.

Why?

Depending on the type of fuel effect used with the fire, the aeration setting on the burner may have changed from that specified in the installer guide.

What to do?

Ignore any reference to checking the aeration setting of the burner and the aeration setting illustration at the start of the 'Servicing and Parts Replacement' section. The aeration setting is factory set and will not require adjustment.

© Baxi Heating U.K. Limited 2009.

5135413/01



AERATION ADDENDUM

This addendum is for the following natural gas models: 939, 940 & 951. It must be read in conjunction with the installer and owner guide supplied with the fire.

Why?

Depending on the type of fuel effect used with the fire, the aeration setting on the burner may have changed from that specified in the installer guide.

What to do?

Ignore any reference to checking the aeration setting of the burner and the aeration setting illustration at the start of the 'Servicing and Parts Replacement' section. The aeration setting is factory set and will not require adjustment.

© Baxi Heating U.K. Limited 2009.