

SPIGOT EXTENSION KIT GUIDE (0595191)

This spigot extension can be fitted to the following models:
337, 347, 338, 339, 340, 341, 342, 348, 349.

Contents

Spigot extension (1 off)

Screw (1 off)

This spigot extension is designed to be fitted to the gas fire spigot in installations where the gas fire is bought forward from the fireplace opening, e.g. due to the low forward projection of a mantle shelf above the fireplace.

This fitting instruction must be used in conjunction with the installation guide supplied with the fire.

Fitting the spigot extension.

1. Determine the length of extension required. This can be done by placing the fire in position and measuring the distance between the closure plate and the back edge of the flanges at the side of the heat engine.
2. The spigot extension shall pass through the closure plate and extend for at least 38mm. There shall be a minimum clearance of 50mm between the end of the spigot extension and any surface.
3. It is recommended that the spigot extension is located at least 20mm from the end of the spigot.
4. The spigot extension has fixing holes already in place.
5. Cut the spigot extension to the required length.
6. Push the spigot extension onto the spigot with the fixing hole facing upward.
Never force or cut the spigot extension so that it goes into the spigot. Always fit the extension to the outside of the spigot.
7. Mark the position of the fixing hole and remove the spigot extension.
8. Where marked, drill a hole using a 3mm – 3.2mm diameter drill bit (No.8). Push the spigot extension onto the spigot and fix into place using the screw supplied in this kit.

Important Note: A spillage test must be made before the installed appliance is left with the customer. Please refer to the 'Spillage check' section in the installer guide.