



SETTING THE TEXT **DISPLAY FOR THE RD i SERIES**







) -----Off (Economy) R from: -- : 10 **REPEAT OPERATIONS 4 - 8 TO SET THE** from: -- : Heating program Heating program SECOND (Set 3 & 4) AND THIRD (Set Heating program 5 & 6) ON / OFF PERIODS. PRESS CHANGE TO PRESS OK TO ACCEPT PRESS CHANGE TO SELECT THE FIRST OFF THE FIRST OFF PERIOD. SELECT THE OFF TIME.





SETTING THE ECONOMY TEMPERATURE (The boiler will override the timer to warm the rooms to the temperature set). ↑↓ †↓ ţΙ Select Select Time/day/holidays Change value Heating program

PRESS BACK TWICE TO RETURN TO HEATING

Economy temperature

Heating program 2 3 Economy temperature

PRESS CHANGE TO SELECT ECONOMY TEMPERATURE, THEN PRESS OK

- 5.5∞C Economy temperature

PRESS CHANGE TO SELECT THE TEMPERATURE, THEN PRESS OK

Heating program Economy temperature Heating

PRESS BACK TO RETURN TO HEATING

Heating Hot water Info Settings

Set 1. operating mode ↑↓

SELECT THE START TIME,

from: 8 : 10

Heating program

PRESS CHANGE TO

THEN PRESS OK

PRESS BACK AGAIN TO RETURN TO THE MAIN MFNU

WORCESTER Bosch Group

SETTING THE TEXT DISPLAY FOR THE RD i SERIES

